

Applications and Materials for Magnetohydrodynamic Microfluidics

Student: Devin Benson

Mentor: Dr. Ingrid Fritsch

Biological Sensors

Undergraduate School / Major: Harding University/Biomedical Engineering

Background/Relevance

- Magneto hydrodynamics (MHD) as a pumping system, enables the ability to detect and follow the effect of treatment and improve accessibility of and decrease cost of healthcare through microfluidics.
- MHD follows the right hand rule $\text{Force}_{\text{MHD}} = \text{current} \times \text{magnetic field}$.
- PEDOT(Poly 3,4-ethylenedioxythiophene) improves electrical response.
- PEDOT morphology can be modified by changing solvent and electrolyte increasing current and charge capacity creating a better pumping system allowing for longer operational time without need to recharge the film.

Innovation

- Conducting polymer as redox species
- Improve polymer electrochemical properties through different electrodeposition conditions.

Key Results


- Electrodeposition from PC and LiClO_4 provides maximum charge density.
- Increased scan rate during deposition decreases current density.
- PEDOT film is more stable in aqueous solution than in organic solution.
- Able to maintain flow rate above $20 \mu\text{m/s}$ for more than 200 s at $30 \mu\text{A}$ applied current, longer than previous attempts (75 s).

PEDOT Deposition Solution	Current Density A/m^2 (85% PBS and 15% glycerol)	Charge Density mC/cm^2	Current Density A/m^2 (0.1 M NaCl)	Charge Density mC/cm^2	Current Density A/m^2 (PBS)	Charge Density mC/cm^2
0.1 M LiClO_4 in Propylene Carbonate	655 ± 4	75.7 ± 0.6	1005 ± 23	118.7 ± 7	1797 ± 264	92.7 ± 4.5
0.1 M TBAPF ₆ in Propylene Carbonate	880 ± 1.8	54.2 ± 0.1	1167 ± 2	57.7 ± 0.1	2631 ± 8	67.0 ± 4.8

Current and charge response for PEDOT film deposited from PC with LiClO_4 or TBAPF₆ as electrolytes.

Approach


- Deposit PEDOT onto gold electrodes using cyclicvoltammetry while varying deposition parameters
 - Used acetonitrile and propylene carbonate (PC) as solvents, and LiClO_4 and TBAPF₆ as electrolytes.
- Characterized modified electrodes using chronoamperometry (CA)
- MHD study using chronopotentiometry.
 - Particle image velocimetry software used to determine velocity profile.



MHD experiment setup. [Nash, C. K Modified-Electrodes for Redox-(MHD) Pumping for Microfluidic Applications. Ph D. Dissertation, University of Arkansas, Fayetteville, AR 2014]

Conclusions

- PEDOT deposited from propylene carbonate and LiClO_4 can be effectively used as an immobilized redox species for use as an effective MHD pumping system.
- Films produced from propylene carbonate have higher stability.
- The use of an organic solvent has significant current and charge density improvements over water. This means MHD pumping can produce faster velocities and pump fluid farther.
- Future work: Optimize pumping system for use with cell cytometry and other lab-on-a-chip applications.



Average flow velocity during MHD study with $30 \mu\text{A}$ applied current and 0.37 T magnetic field.

Research Funded by National Science Foundation REU Grant # EEC-1359306 and CBET-1336853 and the Arkansas Biosciences Institute, the major research component of the Arkansas Tobacco Settlement Proceeds Act of 2000. Summer 2015

Thanks to Foyzal Khan for his assistance and guidance with this project

PEDOT Deposition Solution	Current Density A/m² (85% PBS and 15% glycerol)	Charge Density mC/cm²	Current Density A/m² (0.1 M NaCl)	Charge Density mC/cm²	Current Density A/m² (PBS)	Charge Density mC/cm²
0.1 M LiClO₄ in Propylene Carbonate	655 ± 4	75.7 ± 0.6	1005 ± 23	118.7 ± 7	1797 ± 264	92.7 ± 4.5
0.1 M TBAPF₆ in Propylene Carbonate	880 ± 1.8	54.2 ± 0.1	1167 ± 2	57.7 ± 0.1	2631 ± 8	67.0 ± 4.8